

System User Guide - Resolute Cup

1. Collect your event supplied ProStart, Torch, and phone at the daily morning briefing. This hardware is pre-registered to your boat. You do not need to do this if you are not sailing the first race of the day.
2. At the end of each day, return the event supplied phone, ProStart, and Torch from the boat you brought back to the dock for charging to a Velocitek rep at the NYYC Sailing Office. You do not need to do this if you are not sailing the last race of the day.
3. On the boat, please keep your event supplied Torch in its bracket on the aft face of the cockpit, and your ProStart snapped into its cradle for the entirety of the day. Please turn your ProStart and Torch on when you leave the dock and store your event supplied phone, powered on, in the dry box mounted on the aft face of the cockpit. The supplied phone will automatically pair with your ProStart and Torch in the background.
4. Before the first warning of the day, the RC will announce when the signal and pin boats are on station and transmitting their position. Before the line ends are transmitting your ProStart will display “- - -” for distance to line.
5. Before every warning signal, your ProStart will automatically switch into start mode and the timer section will start showing a countdown to your start.
6. At 0:00, the ProStart will flash the boat's final distance to line for several seconds. On boats that are clear this will be a positive number or zero. On boats that are OCS this will be a negative number.
7. On boats that were clear at the start, the ProStart will automatically switch into race mode (Magnetic Heading / SOG).
8. On boats that were OCS at the start, the ProStart will flash the negative final distance to line for 1-2 seconds and will then display "OCS" for 30 seconds. The message "OCS" will be displayed for 30 seconds regardless of whether the boat has restarted or not.
9. Between races, the ProStart will stay in race mode until the next start is scheduled by the RC.
10. To turn off the ProStart press and hold the power button (center top) for 5 seconds. The ProStart must be turned off anytime the RC has displayed signal flag F.

Join the WhatsApp group Resolute Cup Velocitek Users:



<https://chat.whatsapp.com/LSYqO93IH1zK73CduGj6vB>